

### Hipot (Withstanding Voltage) & Insulation Resistance Tester



\* When the output voltage is 1.0 kV or greater

# Hipot (Withstanding Voltage) & Insulation Resistance Tester TOS5300 Series

The PWM amp system provides highly-stable output 5 kV/100 mA (500 VA) AC Hipot (withstanding voltage) test 6 kV/maximum output 50 W DC Hipot (withstanding voltage) tester (TOS5301) 25 V-1000 V (7 steps), 500 V or greater, up to 5.00 GΩ Insulation Resistance test High-precision measurement ±1.5 % of reading (with voltmeter 500 V or higher, Ammeter 1 mA or higher) Rise time/Fall time control Key lock function and Protection cover for key operation Equipped with USB interface



# **Highly stable**

Newly developed, high-efficiency PWM switching amplifier !



# ▲Output voltage wave form

Providing a stable output of high voltage without being affected by AC line variation. Ensure the user to perform highly reliable testing with confidence, even in regions with large voltage variations. (Input

voltage fluctuation rate: ±0.3%)



Equipped with a Rise time/ Fall time control function Prevents from an excessive stress applied to the EUT or for standard tests.



# **Pursuing usability** and safety

# All new design of the control panel and output terminals!

Eliminates the projected components of output terminals, and equips with a new type of the LOW terminal. Pursuing the improvement of safety and a convenience in production line, such as providing the protection cover for the front panel.

# ▲Output termin Left : HIGH (red)



Right : LOW (black, with lock function)

▲View with the protection cover removed from front panel

# **Supporting the** World-wide input voltage

Reducing

the tact time

Increasing the productivity!

Capable of setting the test time from 0.1s

### Usable globally !

Usable in any country without changing the input power supply.

### Selectable output frequency !

The instrument not rely on the input power environment. Supplying the stable test voltage with 50/60 Hz frequencies.



# Lightweight & **Compact design**

Increasing your work efficiency!

Weighs Approx. 15 kg 40% lighter than conventional models \*Compared to TOS5300 and TOS8870A





When the output voltage is 1.0 kV or greater

Hipot (Withstand-Voltage) & Insulation Resistance Tester



The "TOS5300 Series" is a series of test instruments used in Hipot (withstanding voltage) tests and insulation resistance tests, two of the four tests regarded as necessary for ensuring the safety of electrical products. With an output of 5 kV/100 mA (AC) and 6 kV/10 mA (DC), the series can be used in Hipot (withstanding voltage) & insulation resistance testing of electronic equipment and electronic parts, based on the requirements of IEC, EN, UL, VDE, JIS, and other international safety standards and the Electrical Appliance and Material Safety Law. Also, the test voltage stability is improved with the adoption of a newly developed switching amplifier. Since the output voltage can be kept constant even when the AC line voltage or frequency changes, consistent testing can be performed, even when the power supply environment is in an unstable region. The TOS5300 is also equipped with a number of features that are capable of meeting a variety of test needs. It is a new low-cost standard model that provides thorough operability, reliability and safety.

Applied test / Model	TOS5300	TOS5301	TOS5302
AC Hipot (Withstanding voltage) test (ACW)	<b>v</b>	v	<b>v</b>
DC Hipot (Withstanding voltage) test (DCW)		v	
Insulation Resistance test (IR)			~

Features and Functions

●ACW: 5 kV/100 mA; DCW: 6 kV/50 W ●IR: 25-1000 V (7 steps)/500 V or greater, up to 5.00 GΩ ●High-precision measurement ±1.5 % of reading (Voltage: 500 V or greater ; Current: 1 mA or more) ORise time / Fall time control function ODischarge function Oworld-wide input voltage OAUTO function ●USB interface ●Panel memory function (3 sets) ●Key lock and Protection cover for panel operation

2

# The achievement of AC Hipot (Withstanding voltage) testing with a constant stable output!

# The output waveform is essential factor in Hipot (Withstanding voltage) testing!

A conventional Hipot (Withstanding voltage) tester boosts and outputs the AC line's input voltage through the use of a slide transformer. With this slide transformer system, input voltage fluctuations will affect the output, preventing tests from being performed properly. At times, the application of distortion voltage applied to the EUT may cause a failure of new product (accelerating a deterioration of components). Since the TOS5300 Series equips with a highefficient PWM amplifier that can output a stable high-voltage without being affected by the variation of AC power line, users can perform "safe", "stable", and highly "reliable" tests with confidence, even in regions with large voltage variations.

# Realizing high-precision measurement with high-resolution and high-speed judgement

Equipped with a high-accuracy, high-resolution of True RMS measurement circuit, including a Voltmeter with  $\pm 1.5$  % of reading (500 V or greater) / minimum resolution of 1V, and an Ammeter with  $\pm 1.5$  % of reading (1 mA or more) / minimum resolution of 1  $\mu$ A. In addition, it is also equipped with an Auto range function. The Lower limit judgment accuracy achieves a level of performance equivalent to the Upper limit judgment accuracy that enables to detect for such a poor contact or disconnections of test leads. Moreover, it realizes the fast judgment by the test time of 0.1 second, while reliable testing can be performed, thanks to high-precision, high-resolution, high-speed measurement and the judgment functions.



▲ AC Hipot (Withstanding voltage) test settings display (example)



# Supporting the World-wide input voltage



#### Usable globally !

Usable in any country, without changing the input power supply.

### Selectable output frequency !

The instrument not rely on the input power environment. Supplying the stable test voltage with 50/60 Hz frequencies.

# **Reducing the tact time**

Reduction of the tact time leads to improve the productivity. However, it has been an issue that reducing the tact time may cause to worsen the measurement accuracy when the test time is faster than the measuring response speed. The TOS5300 series has been achieved to set the test time from 0.1 s.

### (Model TOS5301)

# 6 kV/50 WDC Hipot (Withstanding voltage) test

Capable to perform DC Hipot (Withstanding voltage) test up to 6 kV. (Model TOS5301) Equipped with a stable DC/DC converter with a low-ripple and the load variation of 3 % or less.

# Insulation resistance test for 25 V to 1000 V\*

The TOS5302 is equipped with an insulation resistance tester. The test voltages can be set from 25 V, 50 V, 100 V, 125 V, 250 V, 500 V and 1000 V. And for setting at 500 V and above, it can perform the insulation resistance test up to  $5.00 \text{ G}\Omega$ .

\*At 500 V and above, measurements up to 5.00 G  $\!\Omega$  are possible.

# Protection cover prevents physical operation error in the production site

Prevents a physical operation error by installing the protection cover on the control keys.



In many cases, workers on electronic equipment production lines and inspection lines are not technical experts. Therefore, it is possible that the operators may change setting conditions and make operation errors. In order to prevent from such cases, the TOS5300 is equipped with a key lock function and a protection cover to disable a physical key operation from the front panel.



Storing the protection cover for the key operation to the base of unit. ▶ During the periods of operation with the protection cover removed, such as when the test conditions are frequently changed and tests are performed repeatedly, the protection cover can be stored at the base.

# New design of output terminal improves safety and functionality

# Eliminates the projected components from the front panel. The new design of LOW terminal.

In consideration of safety for the operator and the environment, the output terminal of HIGH-side has been placed in the most distant location from the control area. The free rotation machanisim protects from twisting (or breaking) of the cable. Also, with having the lock function for the LOW terminal on the main unit, the metal plate is no longer attached to the test lead of LOW-side, and it makes to resist damage to the test lead. Because of elimination of these projected components, the TOS5300 can avoid from unexpected accidents such as when the unit travels to other location. And also when the test lead is snagged on something, or unexpected stress is applied on the test lead, the High (High-voltage) test lead is designed to disconnect easily, but the Low (ground) test lead is designed to resist disconnection.

In order to prevent the insertion error, the color coding of the cable are classified to HIGH (red) and LOW (black) , and the plug shape of terminal are also different design.



▲ Flat surface design of the HIGH terminal with free rotation mechanism, and the LOW terminal with lock function



It could be a cause of defect if the cable are incorrectly wired for the HIGH (High-voltage) side and LOW (Low-voltage) side. In order to prevent the insertion error, the protection plate is attached to the Low-voltage (Black) test lead.

# Monitoring the output voltage and protection when applying an overvoltage by the operation error

# LIMIT VOLTAGE function

Prevents the user from setting a test voltage that exceeds the preset voltage.



#### Monitoring output voltage function

If the output voltage exceeds the setting voltage of  $(\pm 350 \text{ V})$ , it turns off the output and the system switches to PROTECTION mode. In order to handle kilo's of high voltage when the Hipot (Withstand voltage) and insulation tests are conducted, there are number of safety measures are required to take place. Having with these functions

improve, the operational safety and the protection for the EUT.

Tek Stop

# **Rise time / Fall time control function**

#### Rise time control function

The Rise time control function enables you to increases the test voltage gradually to reach the setting voltage while the AC Hipot (Withstanding voltage) test is conducted. The voltage rise time can be set from 0.1 s to 10.0 s at a resolution of 0.1 s.

#### Fall time control function

The Fall time control function enables you to decrease the test voltage gradually when the PASS judgment is made at the AC Hipot (Withstanding voltage) test. The voltage fall time is fixed at 0.1 s. (OFF is also selectable).

# POINT

The rise time control function is to prevent the EUT (test object) from being exposed to stress that exceeds the required amount. The Hipot (Withstanding voltage) test is conducted to verify the safety performance of the EUT and which test voltage for Hipot (Withstanding voltage) test is applied approximately five to ten times greater than the voltage that handles by the EUT. If a high voltage is applied rapidly with no rise time, the transitional large voltage (current) will be occurred, and it may cause a damage to the EUT. If, as a result of the test, the EUT is suffered of the insulation (dielectric) breakdown, the failure of defect can easily be identified without any problem. However, when breakage is occurred partially, it becomes hard to identify the problem. In other words there are cases in which "at a glance, a Hipot (Withstanding voltage) test appears to have been successfully passed, however, the fact is found that the insulation performance has degraded." In such cases there is a potential risk of danger that the insulation failure will occur after the EUT has been released into the market as a commercial product. The result of testing performed to confirm safety may cause the loss of product's safety. For this reason, safety standards stipulate the procedure of Hipot (Withstanding voltage) test, and the test voltage must be gradually increased to the specified voltage when the test is performed. The rise time control function adopted in the in the TOS5300 Series can set the voltage rise time from 0.1

s to 10.0 s (at a resolution of 0.1 s) and also it is capable to set the 50 % (fixed) of the applied test voltage. In addition, the fall time control function enables to decrease the test voltage gradually after the completion of a PASS judgement. The voltage fall time is fixed at 0.1 s (OFF is also selectable).



▲ Start voltage can be set at 50 % of the test voltage.

# Examples of Safety Standards (Routine Tests)

Ch4 1.00kV

▲Fall time control waveform (example)

420 0mc A Ch1 3

80.00 %

#### •IEC60950/J60950 - Information processing equipment

The test voltage applied to the insulation part should be increased gradually from zero to the specified voltage, then hold at the specified voltage for 60 seconds.

#### IEC60335/J0335 - Home appliances

The initial test voltage should be applied less than half of the specified voltage, then gradually increase to the specified voltage.

#### IEC60065/J0065 - Audio/video

The initial test voltage should be applied less than half of the specified voltage, then rapidly increase to the specified voltage and hold for 1 minute.

# ●IEC61010/JIS C 1010

#### -Measurement equipments

Avoids any detectable transient phenomenon, the test voltage should be increased gradually to the specified voltage within 5 seconds, then hold at the specified voltage for 5 seconds.

#### Q.What is a Hipot (Withstanding voltage) test?

A. Withstanding test also called a dielectric strength test or Hipot test, a withstanding voltage test is intended to verify whether an electrical product or part has sufficient dielectric strength with respect to the voltage being handled.

#### Q.What is PASS / FAIL criteria ?

A Chi C

1120 0mc

20.00 %

Ch4 1.00kV

▲Rise time control waveform (example)

A. It is considered as "Electrical breakdown" when the current exceeds the limit value flowing through the insulated section during a test. If "the Electrical breakdown" does not occur, the insulator is determined to have sufficient insulating strength.

#### Q.How is the test conducted?

A. Apply the voltage with much higher stress than it would normally be applied to the insulated section for the specified time period.
 While testing, it evaluates to verify whether any insulation breakdown has occurred on the insulator.

# **Interlock feature**

The product is equipped with an interlock function that operates together with external devices to interrupt output. To ensure the safe operation of tester, the interlock function activates when the SIGNAL I/O connector pins number 1 and 13 are opened, and when they are short-circuited, the interlock function is released.





▲The picture shown above indicates the caution sign of "HI VOLTAGE DANGER " with a chain surrounding the test site.

# Discharge feature (Model TOS5301 / TOS5302)

Equipped with a forced discharge function that forcibly discharge the electricity which has been charged in the EUT after the completion of DC Hipot (Withstanding voltage) test or insulation resistance test.



#### Q.What is an insulation resistance test?

A. An insulation resistance test is to measure the resistance value of insulator and verify that whether the insulator has a sufficient performance. It is similar to the Hipot (Withstanding voltage) test that confirms the function or performance of an insulator, and it should be the required conditions to prevent the accidents from an electrical shock and fire.

#### Q.What is the procedure of testing?

A. In many cases, after moisture is absorbed (or is not absorbed in some cases), 500 volts or other specified value of DC voltage is applied, and the resistance value is measured from the current flowing.

# Upper limits / Lower limits setting function

It automatically detects connector lead breaks and disconnections of wiring by measuring extremely small amounts of current that flows when voltage is applied to the EUT.



▲Example setting display of Upper limit, Lower limit, and Test time

# POINT

Normally, even with a good-quality EUT, a certain degree of leakage current flows. If the current value is set at slightly smaller than the specific range of the EUT, it is useful in detecting breaks of the test lead and faulty connections, which enables tests to be performed with even higher reliability. You can perform testing effectively if you set the lower limit value with LOWER ON during Hipot (Withstanding voltage) test, and the upper limit value with UPPER ON during insulation resistance test.

# **Calibration due notice and Warning function**

To assure the traceability of periodic calibration of the product, this function gives a notice of calibration due managed by the builtin real-time clock. Even if the due data has elapsed, it is possible to avoid the oversight of operator with limiting the operation with a display of warning message.

3.Date and Time		1 Menu
Set Date and Time	20 <u>00</u> / 1/30 2:33:48	2 Up
Factory Calibration Calibration Due Control	2000/1/1 3 months	3 Down
Calibration Protection	OFF	Apply

▲Example setting display of Calibration due

#### Q.What is the difference between an insulation resistance test and a Hipot test?

 A. The Hipot (Withstanding voltage) test detects a faulty insulation whether insulation breakdown occurs. In contrast, the insulation resistance test detects faulty insulation by measuring the resistance value.

# Easy setting of test conditions with

### panel memory feature!



To set the test conditions such as test voltage, judgment value and test duration, simply press a key and turn the knob on the front panel. The test conditions can be saved in the panel memory (3 sets).

Panel memory setting key

#### (Model TOS5302)

# **AUTO TEST feature for consecutive testing**

The TOS5302 can perform an AC Hipot (Withstanding voltage) test and an insulation resistance test consecutively.

Either of the following can be conducted :

Insulation resistance test  $\rightarrow$  AC Hipot (Withstanding voltage) test, or AC Hipot (Withstanding voltage) test  $\rightarrow$  Insulation resistance test.



 $\blacktriangle$  Insulation resistance test  $\rightarrow$  AC withstand-voltage test

AUTO				
FUNC	VOLTAGE	UPPER	LOWER	TIMER
ACW	1.50kV	0.02mA	OFF	60.0s
IR	25V	OFF	OFF	0.3s

▲AC withstand-voltage test → Insulation resistance test

# **REMOTE connector & USB interface**



Equipped with the REMOTE connector and USB interface on the front panel are exclusive use for the options. Easy connection with the PC.

# **SIGNAL I/O Connector**

The rear panel is equipped with SIGNAL I/O that provides functions such as start and stop operation and signal output.

				-				
PIN No	Signal name	I/0	TOS5300	TOS53	01			TOS5302
1	INTERLOCK+	I	off, and the TOS5300 S The resistance betwee	If you open the positive and negative terminals, the output is to off, and the TOS5300 Series is switched to Protection mode.Op The resistance between the two terminals is 1.2 k $\Omega$ or greater. The resistance between the two terminals is 1.4 $\Omega$ or less.			ection mode.Open: .2 kΩ or greater. Short:	
2	PM0	Ι	Panel memory selection signa		PM0	PM1	Calle	d Panel Memory Number
3	PM1	I	The selection signal is latched rising edge of the input strobe		н	н	Mem	ory 1
			recall panel memory.	signal to	L	Н	Mem	,
			The selection of memory is prioritized     H     L     Memory 3     L     L     Enables TEST SEL and AUTO SEL sel					
4	NC	—			_			
5	NC	—			_			
6	NC	_			_			
7	NC	—			_			
8	NC	—			_			
9	STB	I	Panel men	nory's st	robe	signa	alinp	ut terminal
10	TEST SEL	I	NA	ACW/DCW set ACW/DCW sig selection signal tes L: ACW L:/ H: DCW Set wit L:/			$\label{eq:selection} \begin{split} & \text{Single/Independent test's} \\ & \text{selection signal/AUTO} \\ & \text{Test's sequence selection} \\ & \text{signal Selection of single} \\ & \text{test with AUTO SEL} \\ & \text{tacW}; \text{H}: \text{DCW} \\ & \text{Selection of AUTO test} \\ & \text{with AUTO SEL} \\ & \text{tacW}: \text{AUTO SEL} \\ & \text{tacW}: \text{R} \\ & \text{H}: \text{IR} \rightarrow \text{ACW} \end{split}$	
11	AUTO SEL	I	NA NA test/single test L: Single test					
12	COM	—	Circuit's common tern	ninal				
13	INTERLOCK-	I	When + terminal and and the system shifts Open: Terminal-to-ter Short: Terminal-to-ter	to the P minal re	rote c esista	tion nce i	statu: s 1.2 k	s. Ω or more
14	HV.ON	0	ON during test and wh between output term		age r	emai	ns	ON during test, while voltage remains between output terminals, and during automatic test (AUTO TEST)
			ON during test (except when voltage is rising or falling)					
15	TEST	0	ON during test (excep	t when	volta	ge is	rising	or falling)
15	TEST PASS	0	ON for at least 0.2 sec.	when P	ASS	nas be	een d	etermined (PASS
		-	ON for at least 0.2 sec.	when P usly ON n value	ASS ł wher over	nas be n PAS accej	een d S HOI ptabl	etermined (PASS D time is set for HOLD
16	PASS	0	ON for at least 0.2 sec. HOLD time) Continuou Continuously ON whe	when P usly ON n value FAIL is d n value	ASS I wher over eterr unde	accep nas be accep ninec	een d S HOI ptabl d eptal	etermined (PASS .D time is set for HOLD e maximum is
16 17	PASS U-FAIL	0	ON for at least 0.2 sec. HOLD time) Continuous Continuously ON whe detected, and UPPER I Continuously ON whe	when P usly ON n value FAIL is d FAIL is d	ASS I wher over eterr unde deter	accep nas be accep ninec	een d S HOI ptabl d eptal	etermined (PASS .D time is set for HOLD e maximum is
16 17 18	PASS U-FAIL L-FAIL	0	ON for at least 0.2 sec. HOLD time) Continuou Continuously ON whe detected, and UPPER I Continuously ON whe detected, and LOWER	when P usly ON n value FAIL is d n value FAIL is d EADY st	ASS I wher over eterr unde deter atus)	accep ninec ninec er acc mine	een d S HOI ptabl d eptal d	etermined (PASS LD time is set for HOLD e maximum is ole minimum is
16 17 18 19	PASS U-FAIL L-FAIL READY	0 0 0 0	ON for at least 0.2 sec. HOLD time) Continuou Continuously ON whe detected, and UPPER I Continuously ON whe detected, and LOWER ON during standby (R	when P usly ON n value AIL is d n value FAIL is d EADY st unction	ASS I wher over eterr unde deter atus)	accep ninec ninec er acc mine	een d S HOI ptabl d eptal d	etermined (PASS LD time is set for HOLD e maximum is ole minimum is
16 17 18 19 20	PASS U-FAIL L-FAIL READY PROTECTION	0 0 0 0	ON for at least 0.2 sec. HOLD time) Continuou Continuously ON whe detected, and UPPER I Continuously ON whe detected, and LOWER ON during standby (RI ON while protection fr	when P usly ON n value FAIL is d n value FAIL is o EADY st unction hinal	ASS I wher over eterr unde deter atus)	accep ninec ninec er acc mine	een d S HOI ptabl d eptal d	etermined (PASS LD time is set for HOLD e maximum is ole minimum is
16 17 18 19 20 21	PASS U-FAIL L-FAIL READY PROTECTION START	0 0 0 0 0 1	ON for at least 0.2 sec. HOLD time) Continuou Continuously ON whe detected, and UPPER I Continuously ON whe detected, and LOWER ON during standby (R) ON while protection fi Start signal input term	when P usly ON n value FAIL is d n value FAIL is d EADY st unction hinal iinal	ASS H wher over leterr unde deter atus) is ac	accep ninecer accep ninecer accep ninecer accep ninecer tivate	een d S HOI otabl d eptal d ed (PF	etermined (PASS .D time is set for HOLD e maximum is ole minimum is ROTECTION ON)
16 17 18 19 20 21 22	PASS U-FAIL L-FAIL READY PROTECTION START STOP	0 0 0 0 1 1	ON for at least 0.2 sec. HOLD time) Continuously ON whe detected, and UPPER I Continuously ON whe detected, and LOWER ON during standby (RI ON while protection fi Start signal input term Stop signal input term Start signal's ENABLE Shifts to the Protectio	when P usly ON n value FAIL is d n value FAIL is d EADY st unction ninal signal ir n status	ASS I when over leterr unde deter atus) is ac	accep ninec accep ninec er acc mine tivate	een d S HOI ptabl d eptab d ed (PF	etermined (PASS .D time is set for HOLD e maximum is ole minimum is ROTECTION ON)





Rear panel

Unless specified otherwise, the specifications are for the following settings and conditions.

The warm-up time is 30 minutes.
 TYP:These are typical values. These values do not guarantee the performance of the product.
 rdng: Indicates the readout value.

• set: Indicates a setting.

• f.s: Indicates full scale.

# Specifications –Withstanding voltage tester

				TOS5300	тс	S5301	TOS5302				
	Output range				0.05 k\	/ to 5.00 kV					
		Accuracy			±(2 % of set + 20 V) v	when no load is connected	t				
		Setting range			0.00 k	/ to 5.50 kV					
		Resolution		10 V steps							
	Max. rated ou	itput *1		500 VA (5 kV/100 mA)							
	Max. rated vo	ltage		5 kV							
	Max. rated cu	irrent		100 mA (when the output voltage is 0.5 kV or greater)							
C output	Transformer rating			500 VA							
ection	Output voltag	e waveform *2		Sine							
		Distortion		If the output voltage is 0.5 kV or more: 3 % or less (when no load or a pure resistive load is connected).							
	Frequency					z or 60 Hz					
	linequeiney	Accuracy				during voltage rise time)					
	Voltage regul			10 %		om maximum rated load t					
	Input voltage					ted; power supply voltage					
	Short-circuit			200		utput voltage is 1.0 kV or	greater)				
	Output metho					switching					
	Output range		-			/ to 6.00 kV					
		Accuracy				f set + 20 V) ad is connected					
		Setting range	-			/ to 6.20 kV					
		Resolution				V steps					
	Max. rated ou		-			5 kV/10 mA)					
			-			6 kV	-				
DC output	Max. rated vo	-	-								
ection	Max. rated cu	1	-	_	1	0 mA	. —				
	Ripple (TYP)	5 kV when no load is connected	-			0 Vp-p					
		Max. rated load	-			0 Vp-p					
	Voltage regul	ation				hanging from maximum ad to no load)					
	Short-circuit	Short-circuit current (TYP)		Short-circuit current (TYP)			40 mA (when ge	neration 6 kV output)			
	Discharge fea	ature				e after test completion sistance: 125 kΩ)					
Start Voltage	9			The voltage at the	start of withstanding vol	tage tests can be set to 50	0% of the test voltage.				
Limit Voltage	9			The test voltage	upper limit can be set .	AC: 0.00 kV to 5.50 kV, D	C: 0.00 kV to 6.20 kV				
	ge monitor featu	Ire					e specified value - 350 V,				
				0	utput is turned off, and pr	otective features are activ	/ated.				
		Scale			6 kV	AC/DC f.s					
	Analog	Accuracy			±:	5 % f.s					
		Indication			Mean-value re	esponse/rms scale					
/oltmeter		Measurement range			0.000 kV to	6.500 kV AC/DC					
		Display			0.0	]□□ kV					
	Digital	Accuracy		V <	500 V: ±(1.5 % of rdng +	20 V); V ≥ 500 V: ±1.5 %	of rdng				
		Response *3		True	e rms/ Mean-value respon	nse rms display Can be s	switched				
		Hold feature		After a test is finished,	the measured voltage is	retained until the PASS o	r FAIL judgment is cleared.				
		Measurement	۵۰۰	0.00 mA to 110 mA		mA to 110 mA	AC: 0.00 mA to 110 mA				
		range			DC: 0.00	mA to 11 mA					
			i = measured c	urrent							
		Display		i < 1 mA	1 mA ≤ i < 10 mA	10 mA ≤ i < 100 mA	100 mA ≤ i				
Ammeter	Digital			ΔΩΩ μ <b>Α</b>	□.□□□ mA	□□.□□ mA	□□□.□ mA				
		Accuracy *4		1.00 n	nA ≤ i: ±(1.5 % of rdng); i	< 1.00 mA: ±(1.5 % of rdn	g + 30 μA)				
				<b>T</b>	me/Mean volue recent	eermedianlow Contra	switched				
		Response *3				nse rms display Can be s					
		Hold feature		After a test is finish	ned, the measured voltag	e is retained until the PAS	S judgment is cleared.				

#### Specifications – Withstanding voltage tester

				TOS5300	TOS5301		то	S5302
			Judgment	Judg	ment method	Display	Buzzer	SIGNAL I/O
	Judgment method and judgment operation		UPPER FAIL	If a current that is greater than the output is turned off, and ar an UPPER FAIL judgment occ Time) of DC withstanding volta also occurs if there is a proble	FAIL LED lights OVER is displayed on the screen		Generates a U-FAIL signal	
			LOWER FAIL	the output is turned off, and a judgment is not performed dur	equal to the lower limit is detected, LOWER FAIL judgment occurs. This ring voltage rise time (Rise Time) of all Il time (Fall Time) of AC withstanding	FAIL LED lights UNDER is displayed on the screen	ON	Generates a L-FAIL signal
ludgment eature			PASS	If the specified time elapses w turned off, and a PASS judgm	ithout any problems, the output is ent occurs.	PASS LED lights	ON	Generates a PASS signal
			<ul> <li>If PASS HOLD is enabled, the PASS signal is generated continuously until the TOS5300 Series receives a STOP signal.</li> <li>The UPPER FAIL and LOWER FAIL signals are generated continuously until the TOS5300 Series receives a STOP signal.</li> <li>The FAIL and PASS buzzer volume levels can be changed.</li> <li>For PASS judgments, the length of time that the buzzer sounds for is fixed to 0.2 seconds.</li> <li>Even if PASS HOLD is enabled, the buzzer turns off after 0.2 seconds.</li> </ul>					
					at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds.			
	Upper limit set	tting	Even if PAS		at the buzzer sounds for is fixed to 0.2 s		AC: 0.01 r	nA to 110 mA
	Upper limit set		Even if PAS	S HOLD is enabled, the buzzer	at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds. AC: 0.01 mA to 110 mA			nA to 110 mA to 110 mA / OFF
		tting	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF	at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 11 mA AC: 0.01 mA to 110 mA / OFF	AC:		
	Lower limit set	tting uracy *4	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA	at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 11 mA AC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 11 mA / OFF	ΑC: % of set + 30 μA)	0.01 mA	to 110 mA / OFF
	Lower limit set	tting uracy *4	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA Calculates the current's true	at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 11 mA AC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 11 mA / OFF S i: ±(1.5 % of set), i < 1.00 mA: ±(1.5 %	AC: % of set + 30 μA) es this value with the	0.01 mA	to 110 mA / OFF
	Lower limit set Judgment acc Current detect	tting uracy *4 tion method	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA Calculates the current's true	at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 11 mA / OFF a < i: ±(1.5 % of set), i < 1.00 mA: ±(1.5 % truns value or mean-value and compare	AC: % of set + 30 μA) es this value with the	0.01 mA	to 110 mA / OFF
	Lower limit set Judgment acc Current detect Calibration	tting uracy *4 tion method	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA Calculates the current's true	at the buzzer sounds for is fixed to 0.2 s r turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 11 mA / OFF s : ±(1.5 % of set), i < 1.00 mA: ±(1.5 % r ms value or mean-value and compare ed with the rms of a sine wave using a p	AC: % of set + 30 μA) es this value with the	0.01 mA	to 110 mA / OFF
	Lower limit set Judgment acc Current detect Calibration	tting uracy *4 tion method me Resolution	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA Calculates the current's true Calibrate	at the buzzer sounds for is fixed to 0.2 s r turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 110 mA / OFF C: 0.01 mA to 11 mA / OFF a ≤ i: ±(1.5 % of set), i < 1.00 mA: ±(1.5 % rms value or mean-value and compare ad with the rms of a sine wave using a p 0.1 s to 10.0 s	AC: % of set + 30 µA) es this value with the ure resistive load	0.01 mA	to 110 mA / OFF
ïme	Lower limit set Judgment acc Current detect Calibration Voltage rise tin	tting uracy *4 tion method me Resolution	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA Calculates the current's true Calibrate	at the buzzer sounds for is fixed to 0.2 s turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 11 mA / OFF a ≤ i: ±(1.5 % of set), i < 1.00 mA: ±(1.5 % erms value or mean-value and compare ed with the rms of a sine wave using a p 0.1 s to 10.0 s 0.1 s	AC: % of set + 30 µA) as this value with the ure resistive load gment occurs)	0.01 mA	to 110 mA / OFF
Time	Lower limit set Judgment acc Current detect Calibration Voltage rise tin Voltage fall tim	tting uracy *4 tion method me Resolution	Even if PAS	S HOLD is enabled, the buzzer 0.01 mA to 110 mA 11 mA to 110 mA / OFF 1.00 mA Calculates the current's true Calibrate	at the buzzer sounds for is fixed to 0.2 s r turns off after 0.2 seconds. AC: 0.01 mA to 110 mA DC: 0.01 mA to 110 mA / OFF DC: 0.01 mA to 11 mA / OFF C: 0.01 mA to 11 mA / OFF a ≤ i: ±(1.5 % of set), i < 1.00 mA: ±(1.5 % erms value or mean-value and compare ad with the rms of a sine wave using a p 0.1 s to 10.0 s 0.1 s / OFF (only enabled when a PASS judged)	AC: % of set + 30 µA) es this value with the ure resistive load gment occurs) R OFF)	0.01 mA	to 110 mA / OFF

#### \*1. Regarding the output time limits:

Taking size, weight, and cost into consideration, the heat dissipation capability of the voltage generator that is used for withstanding voltage tests has been designed to be one half that of the rated output. Use the TOS5300 Series within the following limits. If you use the product in a manner that exceeds these limits, the output section may overheat, and the internal protection circuits may be activated. If this happens, stop testing, and wait until the TOS5300 Series returns to its normal temperature.

Ambient temperature	Upper limit		Pause time	Output time	
AC		50 mA < i ≤ 110 mA	Greater than or equal to the output time	30 min. max.	
t ≤ 40 °C	AC	i ≤ 50 mA	Not necessary	Continuous output possible	
l≦40 C		5 mA < i ≤ 11 mA	Greater than or equal to the output time	1 min. max.	
	DC	i≤5 mA	Greater than or equal to the wait time (WAIT TIME)	Continuous output possible	

(Output time = voltage rise time + test time + voltage fall time)

#### \*2. Regarding the test voltage waveform:

Waveform distortions may occur if an DUT whose capacitance is dependent on voltage (for example, an DUT that consists of ceramic capacitors) is connected as the load. However, if the test voltage is 1.5 kV, the effect of a capacitance of 1000 pF or less can be ignored. Because the product's high-voltage power supply uses the PWM switching method, if the test voltage is 500 V or less, the switching and spike noise proportions are large. The lower the test voltage, the greater the waveform is distorted.

\*3. For both True rms and Mean-value response, 50 ms or above response time is required to satisfy the measurement accuracy.

#### \*4. Regarding ammeter and judgment accuracy:

During AC withstanding voltage tests, current also flows in the stray capacitance of items such as the measurement leads and jigs. This current that flows in the stray capacitances is added to the current that flows in the DUT, and the sum of these currents is measured. Especially if you want to perform judgments with high sensitivity and accuracy, it is necessary to consider methods to limit the current that flows in these stray capacitances, such as by adding upper and lower limits.

Output voltage	1 kV	2 kV	3 kV	4 kV	5 kV
When using 350 mm long test leads that are suspended in air (TYP)	2 µA	4 µA	6 µA	8 µA	10 µA
When using the accessory, high test lead TL31-TOS (TYP)	16 µA	32 µA	48 µA	64 µA	80 µA

### Specifications –Insulation resistance test section

							TOS53	02				
	Output voltag	e			25	5 V, 50 V, 100 V	/, 125 V, 250 V,	500 V, 1000 VDC	C (negative)			
		Accuracy		-0 %, +5 %								
	Max. rated loa	ad	1 W (-1000 V DC / 1 mA)									
	Max. rated cu	rrent		1 mA								
	Ripple	1000 V when no load is connected					2 Vp-p or	less				
Dutput ection		Max. rated load		10 Vp-p or less								
	Voltage regul	ation			1 %	or less (when c	changing from m	aximum rated lo	ad to no load)			
	Short-circuit of	current		12 mA or less								
	Discharge fea	ature			Forced dis	scharge after te	st completion (	lischarge resista	nce: approx. 25 k	Ω)		
	Limit voltage			The test voltage upper limit can be set : 25 V, 50 V, 100 V, 125 V, 250 V, 500 V, 1000 V								
	Output voltag	e monitor feature	If output voltag	e exceeds "10	% of set + 10	V" or is lower t	han "-(10 % of s	et + 10 V)," outpu	ut is turned off, and	d prote	ctive feat	ures are activa
		Scale						OC f.s				
	Analog	Accuracy		±5 % f.s								
		Indication				Me	an-value respo	nse/rms scale				
'olt- neter		Measurement range					0 V to -12	00 V				
leter	Digital	Display		Measured		V < 1		100 V ≤ V < 1			V≤V	
		Accuracy		Displ	lay		± (1 % of rdn	a + 1 V)				
		Accuracy				0.03 MO -		g + 1 v) 2 % of rdng + 2 d	iaite)			
		25 V				25 N	1Ω < R ≤ 125 MΩ	-	•			
	50 V					50 N	1Ω < R ≤ 250 M	2 % of rdng + 2 d 2 / ±5 % of rdng 2 / ±10 % of rdng	•			
	Measurement	100 V				100 N		Ω / ±2 % of rdng Ω / ±5 % of rdng / ±10 % of rdng	I			
measu	range / measurement accuracy	125 V		0.125 MΩ ≤ R ≤ 125 MΩ / ±2 % of rdng 125 MΩ < R ≤ 625 MΩ / ±5 % of rdng 625 MΩ < R ≤ 1.25 GΩ / ±10 % of rdng								
neter		250 V	0.250 MΩ ≤ R ≤ 250 MΩ / ±2 % of rdng 250 MΩ < R ≤ 1.25 GΩ / ±5 % of rdng 1.25 GΩ < R ≤ 2.5 GΩ / ±10 % of rdng									
		500 V	0.50 MΩ ≤ R ≤ 500 MΩ / ±2 % of rdng 500 MΩ < R ≤ 2.5 GΩ / ±5 % of rdng 2.5 GΩ < R ≤ 5 GΩ / ±10 % of rdng									
		1000 V					MΩ ≤ R < 1 GΩ GΩ ≤ R ≤ 5 GΩ /					
	Display *6			R < 1.00 MΩ		R < 10.0 MΩ	10.0 MΩ ≤ R <		.0 MΩ ≤ R < 1.00	GΩ		≤ R ≤ 9.99 GΩ
				] □ kΩ	0.0	<u>α</u> ΜΩ		MΩ	$\Box\Box\Box$ M $\Omega$		□.	$\Box \Box G \Omega$
lold fea	ture			After	a test is finish	ed, the measur	ed resistance is	retained until th	e PASS judgment	is clea	ared.	
urrent	detection respo	nse speed				Can be switch	ed between three	e levels: Fast, M	lid, Slow			
			Judgment	t		Judgment m	nethod		Display		Buzzer	SIGNAL I/O
		UPPER FAIL UPPER FAIL				occurs. This		ayed	ON	Generates a U-FAIL signal		
	Judgment me	thod and judgment	LOWER FA	IL a problem o	occurs during		e time (Rise Tin	it is detected or i ne), the output is	f FAIL LED ligh UNDER is disp on the scree	layed	ON	Generates a L-FAIL signal
ludg-	operation		PASS	ASS off,and a PASS judgment occurs.				PASS LED lig	ghts	ON	Generates a PASS signa	
ment			The UPPER     The FAIL an	FAIL and LOW d PASS buzze dgments, the le	VER FAIL sign r volume level ength of time	hals are genera Is can be chang that the buzzer	ited continuousl ged. sounds for is fi		0 Series receives 300 Series receive ds.			al.
eature				S HOLD is ena	Even if PASS HOLD is enabled, the buzzer turns off after 0.2 seconds.           Upper limit setting range         0.03 MΩ to 5.00 GΩ							
eature	Upper limit se	tting range	Even if PAS		bled, the buzz	zer turns on art	er 0.2 seconds.					
eature	Upper limit se Lower limit se		Even if PAS	0 GΩ	bied, the buzz		er 0.2 seconds.					
eature		tting range	Even if PAS 0.03 MΩ to 5.0 0.03 MΩ to 5.0 Measurement Humidity: 20 % For judgments If the current d	0 GΩ 0 GΩ accuracy + 2 di orh to 70 %rh (r of 200 nA or le etection respon	igits no condensati ess, a test time nse speed is s	on). No interfer e of at least 1.0 set to Mid, a tes	rence caused by seconds is nec st time of at leas	essary. t 0.3 seconds is	•	ms.		
eature	Lower limit se Judgment acc (the same for LOWER)	tting range curacy UPPER and	Even if PAS 0.03 MΩ to 5.0 0.03 MΩ to 5.0 Measurement a Humidity: 20 % For judgments If the current d If the current d	0 GΩ 0 GΩ accuracy + 2 di orh to 70 %rh (r of 200 nA or le etection respon	igits no condensati ess, a test time nse speed is s	on). No interfer e of at least 1.0 set to Mid, a tes	rence caused by seconds is nec st time of at leas	essary.	necessary.	ms.		
eature	Lower limit se Judgment acc (the same for LOWER) Voltage rise ti	tting range curacy UPPER and	Even if PASs 0.03 M $\Omega$ to 5.0 0.03 M $\Omega$ to 5.0 Measurement : Humidity: 20 % For judgments If the current d If the current d 10 ms (TYP)	0 GΩ 0 GΩ accuracy + 2 di 5rh to 70 %rh (r of 200 nA or le etection respon etection respon	igits no condensati ess, a test time nse speed is s nse speed is s	ion). No interfer e of at least 1.0 set to Mid, a tes set to Slow, a te	rence caused by seconds is nec st time of at leas	essary. t 0.3 seconds is	necessary.	ms.		
ime	Lower limit se Judgment acc (the same for LOWER)	tting range curacy UPPER and	Even if PAS 0.03 MΩ to 5.0 0.03 MΩ to 5.0 Measurement a Humidity: 20 % For judgments If the current d If the current d	0 GΩ 0 GΩ accuracy + 2 di of to 70 %rh (r of 200 nA or le etection respon etection respon	igits to condensati ess, a test time nse speed is s nse speed is s off (TIMER Of	ion). No interfer e of at least 1.0 set to Mid, a tes set to Slow, a te	rence caused by seconds is nec st time of at leas	essary. t 0.3 seconds is	necessary.	ms.		

\*5. Humidity: 20 %rh to 70 %rh (no condensation). No bends in the test leads. \*6. R = measured insulation resistance

#### **Specifications** – Other features / Interfaces

		TOS5300	TOS5301		TOS5302			
Double action	feature	Tests can only be started by pressing and re	leasing STOP and then pressi	ing START withir	0.5 seconds of releasing the STOP switch			
Length of time	to maintain a PASS judgment result	You can set the length of time t	to maintain a PASS judgment:	50 ms, 100 ms,	200 ms, 1 s, 2 s,5 s, or HOLD.			
Momentary fea	ature	Tests ar	e only executed while the STA	ART switch is held	d down.			
Fail mode feat	ure	This feature enables you to prevent remo	tely transmitted stop signals fr	from clearing FAI	L judgments and PROTECTION modes.			
Timer feature		This fe	ature finishes tests when the s	specified time ela	apses.			
Output voltage	e monitor feature		e exceeds "setting + 350 V" or					
			tches to PROTECTION mode,					
Memory Up to three sets of test conditions can be saved to memory.					· · · · · · · · · · · · · · · · · · ·			
Key lock Locks panel key operations (settings and changes).				,				
Protective feat	tures	Under any of the following conditions, the						
		and s	tops testing. A message is disp		reen.			
	ock Protection		An interlock signal has bee					
Powe	r Supply Protection		An error was detected in the	1 11 2				
Volt Error Protection While monitoring the output			1 0 0	utput voltage, a voltage outside of the rated limits was detected.				
, on a		· ·	oltage tests: ±350 V Insulati		, ,			
Over	Load Protection	During a withstanding voltage test, a value that is greater than or equal to the output limit power was specified.						
			ng voltage test: 550 VA. DC wit		,			
Over	Heat Protection	The intern	The internal temperature of the TOS5300 Series became too high.					
Over	Rating Protection	During a withstanding voltage test, the	e output current was generated	ed for a length of	time that exceeds the regulated time.			
Calib	ration Protection		The specified calibration period	od has elapsed.				
Remo	ote Protection	A connection to or dis	connection from the front-pan	nel REMOTE con	nector was detected.			
SIGN	AL I/O Protection	The rear-par	nel SIGNAL I/O connector's El	NABLE signal ha	as changed.			
USB	Protection	The USB connector has been discon	nected while the TOS5300 Se	eries was being c	ontrolled through the USB interface.			
System clock		Set in the f	following format: year/month/da	lay hour/minutes	s/seconds.			
Calib	ration date		Set when the TOS5300 Serie	es is calibrated.				
Calib	ration period setting	Sets	the period before the next calil	ibration is necess	sary.			
Notifi	cation of when the calibration	Sets the operation	that is performed when the sp	pecified calibration	on period elapses.			
perio	d elapses	When the TOS5300 Series turns or	ı, it can display a notification o	or switch to the pr	rotection mode and disable testing.			
	USB		USB Specification	n 2.0				
Interfaces	REMOTE		Front-panel 9-pin MINI DIN	N connector.				
menaces	REWOTE	By connecting an optional device	e to this connector, you can co	ontrol the starting	and stopping of tests remotely.			
	SIGNAL I/O		Rear-panel D-sub 25-pin	n connector				

#### **Specifications** – General

			TOS5300	TOS5301	TOS5302				
Display				VFD: 256 × 64 dots + 4 status indicators					
Backup b	pattery life			3 years (at 25 °C or 77 °F)					
Installation location				Indoors, at a height of up to 2000 m					
	Spec guarante-	Temperature	5 °C to 35 °C (41 °F to 95 °F)						
E	ed range	Humidity		20 %rh to 80 %rh (no condensation)					
Environ- ment	Operating	Temperature		0 °C to 40 °C (32 °F to 104 °F)					
ment	range	Humidity		20 %rh to 80 %rh (no condensation)					
	Storage range	Temperature		-20 °C to 70 °C (-4 °F to 158 °F)					
	Storage range	Humidity		90 %rh or less (no condensation)					
	Nominal voltage ra	ange(allowable voltage range)		100 VAC to 240 VAC (90 VAC to 250 VAC)					
Power	Power con- When	n no load is connected (READY)		100 VA or less					
supply	sumption Whe	en rated load isconnected	800 VA max.						
	Allowable frequ	ency range	47 Hz to 63 Hz						
Insulation	resistance (betwee	en AC LINE and the chassis)	30 MΩ or more (500 VDC)						
Withstand	ing voltage (betwee	en AC LINE and the chassis)	1400 VAC, 2 seconds (Routine test) / 1500 VAC, 1 minutes (Type test)						
Earth co	ntinuity			25 AAC, 0.1 Ω or less					
Safety *7	,			h the requirements of the following directive a					
			· · · · · · · · · · · · · · · · · · ·	ive 2014/35/EU*8, EN 61010-1 (Class I*11, Po	<b>3</b> ,				
				n the requirements of the following directive a					
				26-1 (Class A*9), EN 55011 (Class A*9, Group					
Electrom	agnetic compati	bility (EMC) *7 *8		ne maximum length of all cabling and wiring c					
			0	hen using the SIGNAL I/O. The high-voltage	5				
Dimensio			Elect	rical discharges are not occurring outside the	DUI.				
	JIIS			See "Outline drawing."					
Weight			Approx. 14 kg (30.9 lb.)	Approx. 15 kg (33.1 lb.)	Approx. 14 kg (30.9 lb.)				
Accesso	ries			(TL31-TOS): 1set (1 red wire and 1 black wire					
			D-sub 25-pin plug : 1set ; assembly type / High-voltage warning sticker : 1pc. / User's manual : 1pc. / CD-R : 1pc. *9						



Outline drawing

Unit: mm (inch)



- \*7 Does not apply to specially ordered or modified TOS5300s.
- \*8 Limited to products that have the CE mark on their panels. Not be in compliance with EMC limits unless the ferrite core is attached on
- the cable for connection of J1 connector. \*9 This is a Class A equipment. The TOS5300 is intended for use in an indust-
- \*9 This is a Class A equipment. The TOS5300 is intended for use in an industrial environment. This product may cause interference if used inresidential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.
- \*10 This is a Group 1 equipment. The TOS5300 does not generate and/or use intentionally radio-frequency energy, in the from of electromagnetic radiation, inductive and/or capacitive coupling, for the treatment of material or inspection/analysis purpose.
  \*11 This is a Class I equipment. Be sure to ground the TOS5300's protective
- \*11 This is a Class I equipment. Be sure to ground the TOS5300's protective conductor terminal. The safety of this product is only guaranteed when the product is properly grounded.
   \*12 Pollution is addition of foreign matter (solid, liquid or gaseous) that may

12 Pollution is addition of foreign matter (solid, liquid or gaseous) that may produce a reduction of dielectric strength or surface resistivity. Pollution Degree 2 assumes that only non-conductive pollution will occur except for an occasional temporary conductivity caused by condensation.

# Ordering information

**KIKUSUI ELECTRONICS CORPORATION** Southwood 4F,6-1 Chigasaki-chuo, Tsuzuki-ku, Yokohama, 224-0032, Japan Phone: (+81)45-482-6353,Facsimile: (+81)45-482-6261,www.kikusui.co.jp KIKUSUI AMERICA, INC.1-310-214-0000 www.kikusuiamerica.com 3625 Del Amo Blvd, Suite 160, Torrance, CA 90503 Phone : 310-214-0000 Facsimile : 310-214-0014

KIKUSUI TRADING (SHANGHAI) Co., Ltd. www.kikusui.cn

For our local sales distributors and representatives, please refer to "sales network" of our website.

Product Name	Model	Remarks
AC Hipot (Withstanding voltage) & Insulation Resistance tester (ACW/IR)	TOS5302	Hipot (Withstanding voltage) test: AC 5 kV/100 mA Insulation Resistance test: 25V - 1000V
AC/DC Hipot (Withstanding voltage) tester (ACW/DCW)	TOS5301	Hipot (Withstanding voltage) test: AC 5 kV/100 mA, DC 6 kV/50 W
AC Hipot (Withstanding voltage) tester (ACW)	TOS5300	Hipot (Withstanding voltage) test: AC 5 kV/100 mA

# **Options**



■ All products contained in this catalogue are equipment and devices that are premised on use under the supervision of qualified personnel, and are not designed or produced for home-use or use by general consumers. ■ Specifications, design and so forth are subject to change without prior notice to improve the quality. ■ Product names and prices are subject to change and production may be discontinued when necessary. ■ Product names, company names and brand names contained in this catalogue, represent the respective registered trade name or trade mark. ■ Colors, textures and so forth of photographs shown in this catalogue, entry differ from actual products due to a limited if delity in printing. ■ Although every effort has been made to provide the information as accurate as possible for this catalogue, certain details have unavoidably been omitted due to instruct actalogue. ■ If you find any misprints catalogues or errors in this catalogue, errorate and the catalogue to confirm specifications, price, accessories or anything that may be unclear when placing an order or concluding a purchasing agreement. Room 305,Shenggao Building , No.137,Xianxia Road, Shanghai City, China Phone : 021-5887-9067 Facsimile : 021-5887-9069